

## FIG.1A



## FIG.1B

NODE	UNIQUE IP ADDRESS
BASE STATION 2-1	xxx.xxx.0.1
BASE STATION 2-2	xxx.xxx.0.2
BASE STATION 2-3	xxx.xxx.0.3
•	•
•	•
BASE STATION 2-N	xxx.xxx.0.N
MOBILE STATION 1	xxx.xxx.2.1

## FIG.2A



### FIG.2B

NODE	UNIQUE IP ADDRESS	BASE STATION MULTICAST ADDRESS
BASE STATION 2-1	xxx.xxx.0.1	xxx.xxx.1.0
BASE STATION 2-2	xxx.xxx.0.2	xxx.xxx.1.0
BASE STATION 2-3	xxx.xxx.0.3	xxx.xxx.1.0
•	•	•
•	•	•
BASE STATION 2-N	xxx.xxx.0.N	•
MOBILE STATION 1	xxx.xxx.2.1	xxx.xxx.1.0

# FIG.3

MOBILE STATION ADDRESS	BASE STATION ADDRESS	RESULT OF ERROR JUDGMENT	RECEIVED SIGNAL POWER LEVEL
xxx.xxx.2.1	xxx.xxx.0.1	NG	XXX
xxx.xxx.2.1	xxx.xxx.0.2	ок	YYY
xxx.xxx.2.1	xxx.xxx.0.3	NG	ZZZ
•	•	•	•
•	•	•	•
•	•	•	•

FIG.4

